

Ans : (a) : Perfectly flexible cable is used in cable-stayed bridge so that B.M. at every point on cable will be zero.

